



O'HAGIN STANDARD AND O'HAGIN FIRE & ICE ATTIC VENTS INSTALLATION INSTRUCTIONS FOR CLAY TILE ROOF APPLICATIONS


CLAY HIGH PROFILE (S)




1. MARK & CUT a 19 inch x 7 inch hole in the roof deck, centered between layout lines and aligned approximately as shown on the exposure lines. (Note: Set blade to the thickness of the sheathing.)




2. SEAL using a sufficient amount of locally-approved sealant (Class A where required by code for ember and flame resistance) around outer flange of primary vent.




3. ATTACH at 4 inch centers, using roofing nails of sufficient length to penetrate the sheathing.



4. FLASH See general installation notes. When using peel and stick or membrane and mastic methods, apply bottom strip first, then sides, and finally, the top strip.




5. INSTALL the secondary vent cover, bending the wind clip tightly under the preceding course of tile, adjusting for head lap.




6. A. SECURE with roofing nails of sufficient length to penetrate sheathing.

B. SEAL For FIRE&ICE® only, seal any gaps between secondary vent cover and surrounding tiles using locally-approved sealant (Class A where required by code for ember and flame resistance.)


CLAY MEDIUM PROFILE (M)



1. MARK & CUT primary vent opening as shown. Align the bottom of the opening 1/2 to 1 inch above the pan tile layout line as shown.




2. SEAL, ATTACH & FLASH as shown in Steps 2-4 of the 1-piece installation instructions. Apply field tile up to the primary vent, nailing the wire into place.



3. INSTALL the secondary vent, which takes the place of 2 caps and 1 pan tile. Bend the wind clip tightly under the preceding course of tile, adjusting for head lap. Secure as shown in Step 6 of the High Profile installation instructions.

CLAY LOW PROFILE (FLAT)



- Follow Steps 1-4 of the High Profile (S) installation instructions.
- Insert tile between louvered top of secondary vent cover and bottom flanged water channel (see insert). Remove 2 to 3 inches of the tile batten lug on either side of the secondary vent cover for proper fit. For tiles with continuous lugs, a portion of the lug may be removed as needed for wind clip installation. The secondary vent cover takes the place of two field tiles.
- Secure and seal as shown in Step 6 of the 1-piece installation instructions. If necessary, seal underside of secondary vent and top of tile below, using locally-approved sealant (Class A where required by code for ember and flame resistance.)

GENERAL INSTRUCTION NOTES:

- Depending on climate conditions and local best roofing practices, the following methods are acceptable: a) peel and stick; b) three-course and mastic; c) bib-over and mastic; d) membrane and mastic, or finally, e) any other locally approved waterproofing/sealing method. Any waterproof membrane should be held a minimum of 3/4 inch away of the primary vent as installed in Steps 1 through 4, at left, OR, in such a manner as to prevent the "ramping" of water up and over waterproofing material and the raised lip of the primary vent. Prime metal on primary vent, as installed in Steps 1 through 4, at left, if using peel and stick method.
- Seal all penetrations with locally-approved sealant (Class A where required by code for flame resistance) or other approved application. Class A materials should be used on installation of FIRE&ICE® attic ventilation products where required by local code.
- Do not install vents below areas of concentrated water runoff, particularly if partially under, near, or adjacent to solar array installations. Placement assumes gutters are installed and are in good working order in all applicable areas.
- Standard installation at 3:12 pitch or greater.
- All low vents (intake) shall be uniformly installed a minimum of 6 inches above the attic insulation. The width of any eave overhang shall be taken into consideration so, for example, the insulation does not block the attic vent opening.
- All high vents (exhaust) shall be uniformly installed in the second or third course below the ridge assembly (at highest point possible—a minimum of one full course below the ridge) unless prevented by structural framing or other design limitations.
- O'Hagin vents are designed to be part of a complete roofing system. Failure to properly install all components will negatively impact overall performance and will void warranty protections.
- For specific information regarding snow, high velocity wind applications, and Wildland Urban Interface (WUI) applications, contact O'Hagin.

O'HAGIN Superior Attic Ventilation Products

210 Classic Court, Suite 100
Rohnert Park, CA 94928
Toll Free 877-324-0444
Fax 707-588-918

www.ohagin.com



Scan this QR Code with your smart phone to watch easy step-by-step install videos.